$Primer design^{^{\text{TM}}} Ltd$ 

# Tick-borne encephalitis virus

Polyprotein gene genesig® Advanced Kit

150 tests

GENESIG

Kits by Primerdesign

For general laboratory and research use only

# Introduction to Tick-borne encephalitis virus

Tick-borne encephalitis virus (TBEV) is an infectious, arthropod borne virus that affects the human central nervous system. In addition to humans, it also infects ruminants, rodents and certain species of birds. The virus is a member of the genus Flavivirus in the family Flaviviridae and is endemic in several European countries, Russia and some parts of China. Three serotypes of TBEV have been identified worldwide; European, Siberian and Far Eastern. The virus is spherical in shape with a diameter of 40-50 nm. The viral nucleocapsid is 20 -30nm and contains a single stranded positive sense RNA genome of approximately 11.14 kb, encoding 3 structural and 7 nonstructural proteins. The nucleocapsid is surrounded by a host-derived lipid bilayer that contains 2 glycoproteins; membrane protein (M protein) and envelope protein (E protein).

TBEV is primarily transmitted by ticks of the genus Ixodes which serve as both a vector and reservoir of the virus. The European TBEV is primarily transmitted by I. ricinus while the Far Eastern and Siberian subtypes are transmitted mainly by I. persulcates. Humans can also be infected by consuming contaminated unpasteurised dairy products from infected animals although this is rare. Direct person-to-person spread of TBEV is also rare but can occur through blood transfusions or breast feeding. Most infections occur during leisure activities such as hiking, camping or trekking in forested areas where the vectors are abundant. The incidence peaks during the highest period of tick activity which is in spring and early summer, but can occur throughout the year.

The incubation period of TBEV is usually 4 to 28 days and about two thirds of infections are asymptomatic. Milk-borne exposure has a shorter incubation period of 3-4 days. In the early stages of infection the disease often presents itself as a non-specific febrile illness with symptoms including fever, malaise, anorexia, muscle aches, headache and nausea. The most common signs when testing for patients with TBEV are leukopenia and thrombocytopenia. After a few days of remission, 20-30% per cent of patients suffer from the second phase of the disease which involves the central nervous system resulting in aseptic meningitis, encephalitis, or myelitis. Around 10% of the affected patients suffering from this phase would require intensive care and mortality rate is around 1% after onset of the neurological symptoms. The Far Eastern subtype is considered to be the most pathogenic for humans, with a mortality rate of >20%. The Western European subtype is less virulent and less lethal.

# Specificity

The Primerdesign genesig Kit for Tick-borne encephalitis virus (TBEV) genomes is designed for the in vitro quantification of TBEV genomes. The kit is designed to have a broad detection profile. Specifically, the primers represent 100% homology with over 95% of the NCBI database reference sequences available at the time of design.

The dynamics of genetic variation means that new sequence information may become available after the initial design. Primerdesign periodically reviews the detection profiles of our kits and when required releases new versions.

If you require further information, or have a specific question about the detection profile of this kit then please send an e.mail to enquiry@primerdesign.co.uk and our bioinformatics team will answer your question.

### Kit contents

- TBEV specific primer/probe mix (150 reactions BROWN) FAM labelled
- TBEV positive control template (for Standard curve RED)
- Internal extraction control primer/probe mix (150 reactions BROWN)
  VIC labelled as standard
- Internal extraction control RNA (150 reactions BLUE)
- Endogenous control primer/probe mix (150 reactions BROWN)
  FAM labelled
- RNase/DNase free water (WHITE) for resuspension of primer/probe mixes
- Template preparation buffer (YELLOW)
   for resuspension of internal control template, positive control template and standard curve
   preparation

### Reagents and equipment to be supplied by the user

#### **Real-time PCR Instrument**

#### **Extraction kit**

This kit is recommended for use with genesig Easy DNA/RNA Extraction kit. However, it is designed to work well with all processes that yield high quality RNA and DNA with minimal PCR inhibitors.

oasig<sup>™</sup> Iyophilised OneStep or Precision®PLUS OneStep 2X RT-qPCR Master Mix Contains complete OneStep RT-qPCR master mix

**Pipettors and Tips** 

Vortex and centrifuge

Thin walled 1.5 ml PCR reaction tubes

# Kit storage and stability

This kit is stable at room temperature but should be stored at -20°C on arrival. Once the lyophilised components have been resuspended they should not be exposed to temperatures above -20°C for longer than 30 minutes at a time and unnecessary repeated freeze/thawing should be avoided. The kit is stable for six months from the date of resuspension under these circumstances.

If a standard curve dilution series is prepared this can be stored frozen for an extended period. If you see any degradation in this serial dilution a fresh standard curve can be prepared from the positive control.

Primerdesign does not recommend using the kit after the expiry date stated on the pack.

### Suitable sample material

All kinds of sample material suited for PCR amplification can be used. Please ensure the samples are suitable in terms of purity, concentration, and RNA/DNA integrity (An internal PCR control is supplied to test for non specific PCR inhibitors). Always run at least one negative control with the samples. To prepare a negative-control, replace the template RNA sample with RNase/DNase free water.

# Dynamic range of test

Under optimal PCR conditions genesig TBEV detection kits have very high priming efficiencies of >95% and can detect less than 100 copies of target template.

### Notices and disclaimers

This product is developed, designed and sold for research purposes only. It is not intended for human diagnostic or drug purposes or to be administered to humans unless clearly expressed for that purpose by the Food and Drug Administration in the USA or the appropriate regulatory authorities in the country of use. During the warranty period Primerdesign genesig detection kits allow precise and reproducible data recovery combined with excellent sensitivity. For data obtained by violation to the general GLP guidelines and the manufacturer's recommendations the right to claim under guarantee is expired. PCR is a proprietary technology covered by several US and foreign patents. These patents are owned by Roche Molecular Systems Inc. and have been sub-licensed by PE Corporation in certain fields. Depending on your specific application you may need a license from Roche or PE to practice PCR. Additional information on purchasing licenses to practice the PCR process may be obtained by contacting the Director of Licensing at Roche Molecular Systems, 1145 Atlantic Avenue, Alameda, CA 94501 or Applied Biosystems business group of the Applera Corporation, 850 Lincoln Centre Drive, Foster City, CA 94404. In addition, the 5' nuclease assay and other homogeneous amplification methods used in connection with the PCR process may be covered by U.S. Patents 5,210,015 and 5,487,972, owned by Roche Molecular Systems, Inc, and by U.S. Patent 5,538,848, owned by The Perkin-Elmer Corporation.

### **Trademarks**

Primerdesign™ is a trademark of Primerdesign Ltd. genesig® is a registered trademark of Primerdesign Ltd.

The PCR process is covered by US Patents 4,683,195, and 4,683,202 and foreign equivalents owned by Hoffmann-La Roche AG. BI, ABI PRISM® GeneAmp® and MicroAmp® are registered trademarks of the Applera Genomics (Applied Biosystems Corporation). BIOMEK® is a registered trademark of Beckman Instruments, Inc.; iCycler™ is a registered trademark of Bio-Rad Laboratories, Rotor-Gene is a trademark of Corbett Research. LightCycler™ is a registered trademark of the Idaho Technology Inc. GeneAmp®, TaqMan® and AmpliTaqGold® are registered trademarks of Roche Molecular Systems, Inc., The purchase of the Primerdesign ™ reagents cannot be construed as an authorization or implicit license to practice PCR under any patents held by Hoffmann-LaRoche Inc.

### **Principles of the test**

#### **Real-time PCR**

A TBEV specific primer and probe mix is provided and this can be detected through the FAM channel

The primer and probe mix provided exploits the so-called TaqMan® principle. During PCR amplification, forward and reverse primers hybridize to the TBEV cDNA. A fluorogenic probe is included in the same reaction mixture which consists of a DNA probe labeled with a 5`-dye and a 3`-quencher. During PCR amplification, the probe is cleaved and the reporter dye and quencher are separated. The resulting increase in fluorescence can be detected on a range of qPCR platforms.

#### Positive control

For copy number determination and as a positive control for the PCR set up, the kit contains a positive control template.

This can be used to generate a standard curve of TBEV copy number / Cq value. Alternatively the positive control can be used at a single dilution where full quantitative analysis of the samples is not required. Each time the kit is used, at least one positive control reaction must be included in the run. A positive result indicates that the primers and probes for detecting the target TBEV gene worked properly in that particular experimental scenario. If a negative result is obtained the test results are invalid and must be repeated. Care should be taken to ensure that the positive control does not contaminate any other kit component which would lead to false-positive results. This can be achieved by handling this component in a Post PCR environment. Care should also be taken to avoid cross-contamination of other samples when adding the positive control to the run. This can be avoided by sealing all other samples and negative controls before pipetting the positive control into the positive control well.

#### **Negative control**

To validate any positive findings a negative control reaction should be included every time the kit is used. For this reaction the RNase/DNase free water should be used instead of template. A negative result indicates that the reagents have not become contaminated while setting up the run.

#### **Internal RNA extraction control**

When performing RNA extraction, it is often advantageous to have an exogenous source of RNA template that is spiked into the lysis buffer. This control RNA is then co-purified with the sample RNA and can be detected as a positive control for the extraction process. Successful co-purification and qPCR for the control RNA also indicates that PCR inhibitors are not present at a high concentration.

A separate qPCR primer/probe mix are supplied with this kit to detect the exogenous RNA using qPCR. The PCR primers are present at PCR limiting concentrations which allows multiplexing with the target sequence primers. Amplification of the control cDNA does not interfere with detection of the TBEV target cDNA even when present at low copy number. The Internal control is detected through the VIC channel and gives a Cq value of 28+/-3 depending on the level of sample dilution.

#### **Endogenous control**

To confirm extraction of a valid biological template, a primer and probe mix is included to detect an endogenous gene. Detection of the endogenous control is through the FAM channel and it is NOT therefore possible to perform a multiplex with the TBEV primers. A poor endogenous control signal may indicate that the sample did not contain sufficient biological material.

### Resuspension protocol

To minimize the risk of contamination with foreign DNA, we recommend that all pipetting be performed in a PCR clean environment. Ideally this would be a designated PCR lab or PCR cabinet. Filter tips are recommended for all pipetting steps.

1. Pulse-spin each tube in a centrifuge before opening.

This will ensure lyophilised primer and probe mix is in the base of the tube and is not spilt upon opening the tube.

2. Resuspend the primer/probe mixes in the RNase/DNase free water supplied, according to the table below:

To ensure complete resuspension, vortex each tube thoroughly.

Component - resuspend in water		
Pre-PCR pack		
TBEV primer/probe mix (BROWN)	165 µl	
Internal extraction control primer/probe mix (BROWN)	165 µl	
Endogenous control primer/probe mix (BROWN)	165 µl	

3. Resuspend the internal control template and positive control template in the template preparation buffer supplied, according to the table below:

To ensure complete resuspension, vortex each tube thoroughly.

Component - resuspend in template preparation buffer			
Pre-PCR heat-sealed foil			
Internal extraction control RNA (BLUE)			
Post-PCR heat-sealed foil			
TBEV Positive Control Template (RED) *			

<sup>\*</sup> This component contains high copy number template and is a VERY significant contamination risk. It must be opened and handled in a separate laboratory environment, away from the other components.

### **RNA** extraction

The internal extraction control RNA can be added either to the RNA lysis/extraction buffer or to the RNA sample once it has been resuspended in lysis buffer.

DO NOT add the internal extraction control RNA directly to the unprocessed biological sample as this will lead to degradation and a loss in signal.

- 1. Add 4µl of the Internal extraction control RNA (BLUE) to each sample in RNA lysis/extraction buffer per sample.
- 2. Complete RNA extraction according to the manufacturer's protocols.

### OneStep RT-qPCR detection protocol

#### For optimum performance and sensitivity.

All pipetting steps and experimental plate set up should be performed on ice. After the plate is poured proceed immediately to the OneStep amplification protocol. Prolonged incubation of reaction mixes at room temperature can lead to PCR artifacts that reduce the sensitivity of detection.

1. For each RNA sample prepare a reaction mix according to the table below: Include sufficient reactions for positive and negative controls.

Component	Volume
oasig OneStep or PrecisionPLUS OneStep 2X RT-qPCR Master Mix	10 µl
TBEV primer/probe mix (BROWN)	1 µl
Internal extraction control primer/probe mix (BROWN)	1 µl
RNase/DNase free water (WHITE)	3 µl
Final Volume	15 µl

2. For each RNA sample prepare an endogenous control reaction according to the table below (optional):

This control reaction will provide crucial information regarding the quality of the biological sample.

Component	Volume		
oasig OneStep or PrecisionPLUS OneStep 2X RT-qPCR Master Mix			
Endogenous control primer/probe mix (BROWN)			
RNase/DNase free water (WHITE)			
Final Volume	15 µl		

- 3. Pipette 15µl of these mixes into each well according to your qPCR experimental plate set up.
- 4. Pipette 5µl of RNA template into each well, according to your experimental plate set up.

For negative control wells use 5µl of RNase/DNase free water. The final volume in each well is 20µl.

5. If a standard curve is included for quantitative analysis prepare a reaction mix according to the table below:

Component	Volume
oasig OneStep or PrecisionPLUS OneStep 2X RT-qPCR Master Mix	10 µl
TBEV primer/probe mix (BROWN)	1 µl
RNase/DNase free water (WHITE)	4 µl
Final Volume	15 µl

- 6. Preparation of standard curve dilution series.
  - 1) Pipette 90µl of template preparation buffer into 5 tubes and label 2-6
  - 2) Pipette 10µl of Positive Control Template (RED) into tube 2
  - 3) Vortex thoroughly
  - 4) Change pipette tip and pipette 10 µl from tube 2 into tube 3
  - 5) Vortex thoroughly

Repeat steps 4 and 5 to complete the dilution series

Standard Curve	Copy Number
Tube 1 Positive control (RED)	2 x 10 <sup>5</sup> per μl
Tube 2	2 x 10 <sup>4</sup> per μl
Tube 3	2 x 10³ per µl
Tube 4	2 x 10 <sup>2</sup> per µl
Tube 5	20 per µl
Tube 6	2 per µl

7. Pipette 5µl of standard template into each well for the standard curve according to your plate set-up

The final volume in each well is 20µl.

# OneStep RT-qPCR Amplification Protocol

Amplification conditions using oasig OneStep or PrecisionPLUS OneStep 2X RT-qPCR Master Mix.

	Step	Time	Temp
	Reverse Transcription	10 min	55 °C
	Enzyme activation	2 min	95 °C
Cycling x50	Denaturation	10 s	95 °C
	DATA COLLECTION *	60 s	60 °C


<sup>\*</sup> Fluorogenic data should be collected during this step through the FAM and VIC channels

# Interpretation of results


Target (FAM)	Internal control (VIC)	Positive control	Negative control	Interpretation
≤ 30	+/-	+	-	POSITIVE QUANTITATIVE RESULT calculate copy number
> 30	+	+	-	POSITIVE QUANTITATIVE RESULT calculate copy number
> 30	-	+	-	POSITIVE QUALITATIVE RESULT do not report copy number as this may be due to poor sample extraction
-	+	+	-	NEGATIVE RESULT
+/-	+/-	+	≤ 35	EXPERIMENT FAILED due to test contamination
+/-	+/-	+	> 35	*
-	-	+	-	SAMPLE PREPARATION FAILED
+/-	+/-	-	+/-	EXPERIMENT FAILED

Positive control template (**RED**) is expected to amplify between Cq 16 and 23. Failure to satisfy this quality control criterion is a strong indication that the experiment has been compromised.

\*Where the test sample is positive and the negative control is positive with a Cq > 35, the sample must be reinterpreted based on the relative signal strength of the two results:



If the sample amplifies > 5 Cq earlier than the negative control then the sample should be reinterpreted (via the table above) with the negative control verified as negative.



If the sample amplifies < 5 Cq earlier than the negative control then the positive sample result is invalidated and the result should be determined inconclusive due to test contamination. The test for this sample should be repeated.

#### Internal PCR control

The Cq value obtained with the internal control will vary significantly depending on the extraction efficiency, the quantity of RNA added to the RT and PCR reaction and the individual machine settings. Cq values of 28±3 are within the normal range. When amplifying a TBEV sample with a high genome copy number, the internal extraction control may not produce an amplification plot. This does not invalidate the test and should be interpreted as a positive experimental result.

#### **Endogenous control**

The signal obtained from the endogenous control primer and probe set will vary according to the amount of biological material present in a given sample. An early signal indicates the presence of a good yield of biological material. A late signal suggests that little biological material is present in the sample.