

Primerdesign™ Ltd

# Aspergillus flavus

Multidrug resistance protein 1  
(mdr1) gene

genesig® Standard Kit

150 tests

GENESIG

Kits by Primerdesign

For general laboratory and research use only

# Introduction to *Aspergillus flavus*

*A.flavus* was first described as a species in 1809 and together with *A.fumigatus* is one of the most common *Aspergillus* species identified in human infection (particularly in immunosuppressed patients). *A.flavus* is a aflatoxin producing species of *Aspergillus*, this toxin is carcinogenic in some species.

Species of *Aspergillus* vary in colour, size and growth rate. All species can reproduce sexually and asexually, although asexual reproduction is more likely to occur in most species. All species have septate and hyaline hyphae and their hyphae and conidia are separate. *A.flavus* has a genome approximately 37 million bp in length arranged into 8 chromosomes.

*A.flavus* is predominantly found in soil and can cause disease in many agriculture crops such as cereal grain, cottonseed, corn and tree nuts. Infection can be present while the crop is still in the field however symptoms of infection may only appear post-harvest or while the crop is in storage or being transported. *A.flavus* can infect damaged seedlings by sporulation. The pathogen can infect seed embryos decreasing germination and can result in infected seeds being planted in grain crops. Infection can also lead to discoloured embryos, damaged seedlings and killed seedlings which reduces the grade and price of grains.

Aflatoxin infection pre harvest is more common under drought-type conditions, this is because crops are more prone to damage by insects (e.g. lesser cornstalk borer) which are known carriers of fungus spores. High temperatures and high humidity during storage increases the occurrence of *A.flavus* aflatoxin production. In developing countries aflatoxin contaminated grain is a serious health problem, aflatoxins have been linked to liver cancer and various veterinary toxic syndromes.

Real-time PCR can be used for fast detection of *A.flavus*.

# Specificity

This assay will also detect *Aspergillus oryzae* sequences.

If you require further information, or have a specific question about the detection profile of this kit then please send an e.mail to [enquiry@primerdesign.co.uk](mailto:enquiry@primerdesign.co.uk) and our bioinformatics team will answer your question.

# Kit contents

- **A.flavus specific primer/probe mix (150 reactions BROWN)**  
FAM labelled
- **A.flavus positive control template (for Standard curve RED)**
- **RNase/DNase free water (WHITE)**  
for resuspension of primer/probe mixes
- **Template preparation buffer (YELLOW)**  
for resuspension of positive control template and standard curve preparation

# Reagents and equipment to be supplied by the user

## Real-time PCR Instrument

### Extraction kit

This kit is recommended for use with genesig Easy DNA/RNA extraction kit. However, it is designed to work well with all processes that yield high quality RNA and DNA with minimal PCR inhibitors.

### oasig™ lyophilised or Precision® PLUS 2X qPCR Master Mix

This kit is intended for use with oasig or PrecisionPLUS 2X qPCR Master Mix.

## Pipettors and Tips

## Vortex and centrifuge

## Thin walled 1.5 ml PCR reaction tubes

## Kit storage and stability

This kit is stable at room temperature but should be stored at -20°C on arrival. Once the lyophilised components have been resuspended they should not be exposed to temperatures above -20°C for longer than 30 minutes at a time and unnecessary repeated freeze/thawing should be avoided. The kit is stable for six months from the date of resuspension under these circumstances.

If a standard curve dilution series is prepared this can be stored frozen for an extended period. If you see any degradation in this serial dilution a fresh standard curve can be prepared from the positive control.

Primerdesign does not recommend using the kit after the expiry date stated on the pack.

## Suitable sample material

All kinds of sample material suited for PCR amplification can be used. Please ensure the samples are suitable in terms of purity, concentration, and DNA integrity. Always run at least one negative control with the samples. To prepare a negative-control, replace the template DNA sample with RNase/DNase free water.

## Dynamic range of test

Under optimal PCR conditions genesig A.flavus detection kits have very high priming efficiencies of >95% and can detect less than 100 copies of target template.

## Notices and disclaimers

This product is developed, designed and sold for research purposes only. It is not intended for human diagnostic or drug purposes or to be administered to humans unless clearly expressed for that purpose by the Food and Drug Administration in the USA or the appropriate regulatory authorities in the country of use. During the warranty period Primerdesign genesig detection kits allow precise and reproducible data recovery combined with excellent sensitivity. For data obtained by violation to the general GLP guidelines and the manufacturer's recommendations the right to claim under guarantee is expired. PCR is a proprietary technology covered by several US and foreign patents. These patents are owned by Roche Molecular Systems Inc. and have been sub-licensed by PE Corporation in certain fields. Depending on your specific application you may need a license from Roche or PE to practice PCR. Additional information on purchasing licenses to practice the PCR process may be obtained by contacting the Director of Licensing at Roche Molecular Systems, 1145 Atlantic Avenue, Alameda, CA 94501 or Applied Biosystems business group of the Applied Biosystems Corporation, 850 Lincoln Centre Drive, Foster City, CA 94404. In addition, the 5' nuclease assay and other homogeneous amplification methods used in connection with the PCR process may be covered by U.S. Patents 5,210,015 and 5,487,972, owned by Roche Molecular Systems, Inc., and by U.S. Patent 5,538,848, owned by The Perkin-Elmer Corporation.

## Trademarks

Primerdesign™ is a trademark of Primerdesign Ltd.

genesig® is a registered trademark of Primerdesign Ltd.

The PCR process is covered by US Patents 4,683,195, and 4,683,202 and foreign equivalents owned by Hoffmann-La Roche AG. BI, ABI PRISM®, GeneAmp® and MicroAmp® are registered trademarks of the Applied Biosystems (Applied Biosystems Corporation). BIOMEK® is a registered trademark of Beckman Instruments, Inc.; iCycler™ is a registered trademark of Bio-Rad Laboratories, Rotor-Gene is a trademark of Corbett Research. LightCycler™ is a registered trademark of the Idaho Technology Inc. GeneAmp®, TaqMan® and AmpliTaqGold® are registered trademarks of Roche Molecular Systems, Inc., The purchase of the Primerdesign reagents cannot be construed as an authorization or implicit license to practice PCR under any patents held by Hoffmann-La Roche Inc.

# Principles of the test

## Real-time PCR

A *A.flavus* specific primer and probe mix is provided and this can be detected through the FAM channel.

The primer and probe mix provided exploits the so-called TaqMan® principle. During PCR amplification, forward and reverse primers hybridize to the *A.flavus* DNA. A fluorogenic probe is included in the same reaction mixture which consists of a DNA probe labeled with a 5'-dye and a 3'-quencher. During PCR amplification, the probe is cleaved and the reporter dye and quencher are separated. The resulting increase in fluorescence can be detected on a range of qPCR platforms.

## Positive control

For copy number determination and as a positive control for the PCR set up, the kit contains a positive control template. This can be used to generate a standard curve of *A.flavus* copy number / Cq value. Alternatively the positive control can be used at a single dilution where full quantitative analysis of the samples is not required. Each time the kit is used, at least one positive control reaction must be included in the run. A positive result indicates that the primers and probes for detecting the target *A.flavus* gene worked properly in that particular experimental scenario. If a negative result is obtained the test results are invalid and must be repeated. Care should be taken to ensure that the positive control does not contaminate any other kit component which would lead to false-positive results. This can be achieved by handling this component in a Post PCR environment. Care should also be taken to avoid cross-contamination of other samples when adding the positive control to the run. This can be avoided by sealing all other samples and negative controls before pipetting the positive control into the positive control well.

## Negative control

To validate any positive findings a negative control reaction should be included every time the kit is used. For this reaction the RNase/DNase free water should be used instead of template. A negative result indicates that the reagents have not become contaminated while setting up the run.

# Resuspension protocol

To minimize the risk of contamination with foreign DNA, we recommend that all pipetting be performed in a PCR clean environment. Ideally this would be a designated PCR lab or PCR cabinet. Filter tips are recommended for all pipetting steps.

**1. Pulse-spin each tube in a centrifuge before opening.**

This will ensure lyophilised primer and probe mix is in the base of the tube and is not spilt upon opening the tube.

**2. Resuspend the kit components in the RNase/DNase free water supplied, according to the table below.**

To ensure complete resuspension, vortex each tube thoroughly.

| Component - resuspend in water    | Volume |
|-----------------------------------|--------|
| <b>Pre-PCR pack</b>               |        |
| A.flavus primer/probe mix (BROWN) | 165 µl |

**3. Resuspend the positive control template in the template preparation buffer supplied, according to the table below:**

To ensure complete resuspension, vortex the tube thoroughly.

| Component - resuspend in template preparation buffer | Volume |
|--|--------|
| <b>Post-PCR heat-sealed foil</b>                     |        |
| A.flavus Positive Control Template (RED) *           | 500 µl |

\* This component contains high copy number template and is a VERY significant contamination risk. It must be opened and handled in a separate laboratory environment, away from the other components.

# qPCR detection protocol

1. **For each DNA sample prepare a reaction mix according to the table below:**  
Include sufficient reactions for positive and negative controls.

| Component                                 | Volume                      |
|---|-----------------------------|
| oasig or PrecisionPLUS 2X qPCR Master Mix | 10 $\mu$ l                  |
| A.flavus primer/probe mix (BROWN)         | 1 $\mu$ l                   |
| RNase/DNase free water (WHITE)            | 4 $\mu$ l                   |
| <b>Final Volume</b>                       | <b>15 <math>\mu</math>l</b> |

2. **Pipette 15 $\mu$ l of this mix into each well according to your qPCR experimental plate set up.**
3. **Prepare DNA templates for each of your samples.**
4. **Pipette 5 $\mu$ l of DNA template into each well, according to your experimental plate set up.**  
For negative control wells use 5 $\mu$ l of RNase/DNase free water. The final volume in each well is 20 $\mu$ l.
5. **If a standard curve is included for quantitative analysis, prepare a reaction mix according to the table below:**

| Component                                 | Volume                      |
|---|-----------------------------|
| oasig or PrecisionPLUS 2X qPCR Master Mix | 10 $\mu$ l                  |
| A.flavus primer/probe mix (BROWN)         | 1 $\mu$ l                   |
| RNase/DNase free water (WHITE)            | 4 $\mu$ l                   |
| <b>Final Volume</b>                       | <b>15 <math>\mu</math>l</b> |



## 6. Preparation of a standard curve dilution series.

- 1) Pipette 90µl of template preparation buffer into 5 tubes and label 2-6
- 2) Pipette 10µl of Positive Control Template (**RED**) into tube 2
- 3) Vortex thoroughly
- 4) Change pipette tip and pipette 10µl from tube 2 into tube 3
- 5) Vortex thoroughly

Repeat steps 4 and 5 to complete the dilution series

| Standard Curve                         | Copy Number            |
|--|------------------------|
| Tube 1 Positive control ( <b>RED</b> ) | $2 \times 10^5$ per µl |
| Tube 2                                 | $2 \times 10^4$ per µl |
| Tube 3                                 | $2 \times 10^3$ per µl |
| Tube 4                                 | $2 \times 10^2$ per µl |
| Tube 5                                 | 20 per µl              |
| Tube 6                                 | 2 per µl               |

7. Pipette 5µl of standard template into each well for the standard curve according to your experimental plate set up.  
The final volume in each well is 20µl.

## qPCR amplification protocol

Amplification conditions using oasis or PrecisionPLUS 2X qPCR Master Mix.

|             | Step              | Time  | Temp  |
|-------------|-------------------|-------|-------|
| Cycling x50 | Enzyme activation | 2 min | 95 °C |
|             | Denaturation      | 10 s  | 95 °C |
|             | DATA COLLECTION * | 60 s  | 60 °C |

\* Fluorogenic data should be collected during this step through the FAM channel

# Interpretation of results

| Target | Positive control | Negative control | Interpretation   |
|--------|------------------|------------------|--|
| +      | +                | -                | <b>POSITIVE QUANTITATIVE RESULT</b><br>calculate copy number |
| -      | +                | -                | <b>NEGATIVE RESULT</b>                                       |
| + / -  | +                | $\leq 35$        | <b>EXPERIMENT FAILED</b><br>due to test contamination        |
| + / -  | +                | $> 35$           | *  |
| + / -  | -                | + / -            | <b>EXPERIMENT FAILED</b>                                     |

Positive control template (**RED**) is expected to amplify between Cq 16 and 23. Failure to satisfy this quality control criterion is a strong indication that the experiment has been compromised

\*Where the test sample is positive and the negative control is positive with a Cq  $> 35$ , the sample must be reinterpreted based on the relative signal strength of the two results:



If the sample amplifies  $> 5$  Cq earlier than the negative control then the sample should be reinterpreted (via the table above) with the negative control verified as negative.



If the sample amplifies  $< 5$  Cq earlier than the negative control then the positive sample result is invalidated and the result should be determined inconclusive due to test contamination. The test for this sample should be repeated.