

Primerdesign

Z-Path-Eubacteria-std

Eubacteria

Kit version: 1

Target region:

16S ribosomal RNA gene

genesig® DNA Standard Kit

150 tests

G E N E S I G

Kits by Primerdesign

For general laboratory and research use only

Product Description

This genesig® Standard qPCR detection kit targets the 16S ribosomal RNA gene from Eubacteria. The term Eubacteria encompasses all species within the bacteria domain. Eubacteria, also known as “true bacteria”, are single-celled prokaryotic microorganisms that lack a nucleus and membrane-bound organelles. They are found in virtually every environment on Earth, including soil, water, air, and the human body. While many eubacteria play essential roles in ecosystems and human health – such as nutrient cycling and digestion – some species are pathogenic and can cause disease.

Specificity

The kit is designed for the in vitro quantification of Eubacteria genomes and to have a broad detection profile. Specifically, the primers will detect over 91% of sequences available on the NCBI database at the time of last review. The review was conducted on representative genomes from each phylum available on the NCBI database.

The dynamics of genetic variation means that new sequence information may become available after the initial design. If you require further information or have a specific question about the detection profile of this kit, then please send an e-mail to techsupport@primerdesign.co.uk and our team will answer your question.

Kit contents

Quantity	Component	Tube	Cap Colour
1	Eubacteria primer/probe mix (150 reactions) FAM labelled		BROWN
1	Eubacteria positive control template		RED (in foil wrapper)
1	RNase/DNase free water for resuspension of the primer/probe mix		WHITE
2	Template preparation buffer for resuspension of positive control template and standard curve preparation		YELLOW

Reagents and equipment to be supplied by the user

Real-time PCR Instrument

Extraction kit

This kit is recommended for use with genesig® Easy DNA/RNA extraction kit or exsig®Mag. However, it is designed to work well with all processes that yield high-quality nucleic acid with minimal PCR inhibitors.

oasig® lyophilised or PrecisionPLUS® 2X qPCR Master Mix

This kit is intended for use with oasig® lyophilised or PrecisionPLUS® 2X qPCR Master Mix.

Pipettors and filter tips

Vortex and centrifuge

1.5 ml microtubes

qPCR plates or reaction tubes

Kit storage and stability

This kit is stable for shipping at ambient temperature but should be stored at -20°C upon arrival. Once the lyophilised components have been resuspended, they should not be exposed to temperatures above -20°C for longer than 30 minutes at a time and unnecessary repeated freeze/thawing should be avoided. The kit is stable for six months from the date of resuspension under these circumstances.

If a standard curve dilution series is prepared this can be stored frozen for an extended period. If you see any degradation in this serial dilution a fresh standard curve can be prepared from the positive control.

Primer Design Ltd does not recommend using the kit after the expiry date stated on the pack.

Suitable sample material

This kit can be used with all types of samples from various origins. Please ensure that the extracted nucleic acid samples are suitable in terms of purity, concentration, and DNA integrity.

Dynamic range of test

Under optimal PCR conditions the kit can achieve priming efficiencies between 90-110% and detect less than 100 copies of target template. If running a positive control standard curve for a quantitative result, and an efficiency of between 90% to 110% is not achieved, then the run should be repeated with a freshly prepared standard curve.

Principles of the test

Real-time PCR

A target specific primer and probe mix is provided, and this can be detected through the FAM channel.

The primer and probe mix provided exploits the so-called TaqMan® principle. During PCR amplification, forward and reverse primers hybridize to the target DNA. A fluorogenic probe is included in the same reaction mixture which consists of a DNA probe labelled with a 5'-dye and a 3'-quencher. During PCR amplification, the probe is cleaved, and the reporter dye and quencher are separated. The resulting increase in fluorescence can be detected on a range of qPCR platforms.

Positive control

For copy number determination and as a positive control for the PCR set up, the kit contains a positive control template. This can be used to generate a standard curve of target copy number/Cq value. Alternatively, the positive control can be used at a single dilution where full quantitative analysis of the samples is not required. Each time the kit is used, at least one positive control reaction must be included in the run. A positive result indicates that the primers and probes for detecting the target gene worked properly in that particular experimental scenario. If a negative result is obtained the test results are invalid and must be repeated. Care should be taken to ensure that the positive control does not contaminate any other kit component which would lead to false-positive results. This can be achieved by handling this component in a Post PCR environment. Care should also be taken to avoid cross-contamination of other samples when adding the positive control to the run. This can be avoided by sealing all other samples and negative controls before pipetting the positive control into the positive control well.

Negative control

To validate any positive findings, a negative control reaction should be included every time the kit is used. For this reaction the RNase/DNase free water should be used instead of template. A negative result indicates that the reagents have not become contaminated while setting up the run. This is also known as a No Template Control or NTC.

Eubacteria DNA is known to be highly prevalent in the air and environment. The negative control may therefore give a late positive signal due to contamination. See the 'Interpretation of Results' section of the handbook for guidance on results interpretation where environmental contamination is evident.

Resuspension protocol

To minimise the risk of contamination with foreign DNA, we recommend that all pipetting is performed in a PCR clean environment. Ideally this would be a designated PCR lab or PCR cabinet. Filter tips are recommended for all pipetting steps.

1. Pulse-spin each tube in a centrifuge before opening.

This will ensure lyophilised primer/probe mix or template is in the base of the tube and is not lost upon opening the tube.

2. Resuspend the kit components in the RNase/DNase free water supplied, according to the table below.

To ensure complete resuspension allow primer/probe mix to rehydrate for 10 minutes at room temperature. Vortex each tube thoroughly, followed by pipetting up and down 10 times. Failure to mix well can produce poor kit performance.

Component - resuspend in water	Volume
Pre-PCR pack	
Eubacteria primer/probe mix (BROWN)	165 µl

3. Resuspend the positive control template in the template preparation buffer supplied, according to the table below:

To ensure complete resuspension, vortex the tube thoroughly.

Component - resuspend in template preparation buffer	Volume
Post-PCR heat-sealed foil	
Eubacteria Positive Control Template* (RED)	500 µl

* This component contains high copy number template and is a VERY significant contamination risk. It must be opened and handled in a separate laboratory environment, away from the other components.

qPCR detection protocol

1. For each DNA sample prepare a reaction mix according to the table below:
Include sufficient reactions for positive and negative controls.

Component	Volume
oasis® lyophilised or PrecisionPLUS® 2X qPCR Master Mix	10 µl
Eubacteria primer/probe mix (BROWN)	1 µl
RNase/DNase free water (WHITE)	4 µl
Final Volume	15 µl

2. Pipette 15 µl of this mix into each well according to your qPCR experimental plate set up.
3. Pipette 5 µl of DNA template into each well, according to your experimental plate set up.

For negative control wells use 5 µl of RNase/DNase free water (**WHITE**). For positive control wells use 5 µl of the positive control template (**RED**). The final volume in each well is 20 µl.

4. (Optional) Standard curve preparation for quantitative analysis.

For quantitative analysis of the samples, a standard curve dilution series can be prepared using the positive control template (**RED**). This is not required for qualitative analysis.

4.1 Reaction mix preparation for the standard curve.

Include sufficient reactions for each dilution of the standard curve.

Component	Volume
oasig® lyophilised or PrecisionPLUS® 2X qPCR Master Mix	10 µl
Eubacteria primer/probe mix (BROWN)	1 µl
RNase/DNase free water (WHITE)	4 µl
Final Volume	15 µl

4.2 Preparation of a 10-fold standard curve dilution series.

- a. Pipette 90 µl of template preparation buffer (**YELLOW**) into 5 tubes and label 2-6.
- b. Pipette 10 µl of Positive Control Template (**RED**) into tube 2.
- c. Vortex thoroughly.
- d. Change pipette tip and pipette 10 µl from tube 2 into tube 3
- e. Vortex thoroughly.

Repeat steps d and e to complete the dilution series.

Standard Curve	Copy Number
Tube 1 Positive control (RED)	2×10^5 per µl
Tube 2	2×10^4 per µl
Tube 3	2×10^3 per µl
Tube 4	2×10^2 per µl
Tube 5	20 per µl
Tube 6	2 per µl

4.3 Pipette 5 µl of standard template into each well for the standard curve according to your experimental plate set up.

The final volume in each well is 20 µl.

qPCR Amplification Protocol

Amplification conditions using oasig® lyophilised or PrecisionPLUS® 2X qPCR Master Mix.

	Step	Time	Temp
Cycling x50	Enzyme activation	2 min	95 °C
	Denaturation	10 s	95 °C
	DATA COLLECTION *	60 s	60 °C


* Fluorogenic data should be collected during this step through the FAM channel.

Interpretation of results

Target	Positive control	Negative control	Interpretation
+	+	-	POSITIVE QUANTITATIVE RESULT calculate copy number
-	+	-	NEGATIVE RESULT
+ / -	+	≤ 30	EXPERIMENT FAILED due to test contamination
+ / -	+	> 30	*
+ / -	-	+ / -	EXPERIMENT FAILED

The positive control template is expected to amplify between Cq 16 and 23. Failure to satisfy this quality control criterion is a strong indication that the experiment has been compromised.

*Where the test sample is positive and the negative control is positive with a Cq > 30, the sample must be reinterpreted based on the relative signal strength of the two results:



If the sample amplifies > 3 Cq earlier than the negative control Cq, then the sample should be reinterpreted (via the table above) with the negative control verified as negative.

If the sample amplifies < 3 Cq earlier than the negative control Cq, then the positive sample result is invalidated, and a negative call is the correct result.

Notices and disclaimers

This product is developed, designed and sold for research purposes only. It is not intended for human diagnostic or drug purposes or to be administered to humans unless clearly expressed for that purpose by the Food and Drug Administration in the USA or the appropriate regulatory authorities in the country of use. During the warranty period Primer Design Ltd genesig® detection kits allow precise and reproducible data recovery combined with excellent sensitivity. For data obtained by violation to the general GLP guidelines and the manufacturer's recommendations the right to claim under guarantee is expired.

Trademarks

PrecisionPLUS® is a trademark of Primer Design Ltd.

genesig® is a registered trademark of Primer Design Ltd.

oasig® is a trademark of Primer Design Ltd.

exsig®Mag is a trademark of Primer Design Ltd.